

FLEXIBLE BOLLARD – Two piece with chain loop

Installation Procedure:

1. The bollard posts are designed to twist lock into the base plate. (PHOTO 1).
2. Insert the removable bollard post into the rubber base and twist to lock. (PHOTO 2 & 3).
3. If the bollard is too tight to fully twist into the base, lift the bollard (PHOTO 4) and insert locking tool into the recess in the bollard connector. (PHOTO 5).
4. Using the locking tool complete the twist lock action. Note: This may require some effort. (PHOTO 6).

Please note: the bollard is a deliberately tight fit into the base. this is to deter unauthorised removal of the bollard. locking tools are available for purchase if necessary.



1.



2.



3.



4.



5.



6.