

# SKINZ Polyethylene Bollard Sleeves Installation Procedure

**Material:** HDPE + LDPE

**Standard colour:** Safety Yellow – ALL  
Blue – SKZ145-B (only)

**Contains:**  1 x SKINZ bollard sleeve  
 2 x installation foam strips

## INSTALLATION

1. Measure and cut SKINZ to suit your bollard.  
Allow an extra 10mm in length to accommodate foam packing strips (supplied).
2. Place the two foam strips supplied over the top of the bollard at 90° to each other.
3. Slide SKINZ over the foam strips and the bollard.
4. SKINZ maybe fixed to the bollard if required by using appropriate self-tapping screws.
5. Apply optional reflective tape kit (sold separately) into moulded tape recess on sleeve.

	A ID Ø (mm)	B OD Ø (mm)	C Height (mm)	Colour	OPTIONAL Reflective Tape Kit
SKZ105-Y	105	118	1220	Safety Yellow	KITRT25-R
SKZ145-Y	145	158	1420	Safety Yellow	KITRT50-R
SKZ145-B	145	158	1420	Blue	KITRT50-W
SKZ175-Y	175	188	1620	Safety Yellow	KITRT50-R
SKZ225-Y	230	243	1620	Safety Yellow	KITRT75-R

