

MANUAL SWING GATE Installation Procedure



Optional Mounting Post & Receiver Post





WARNING

The gate will not provide optimum performance unless it is installed correctly. For satisfactory gate operation please follow the instructions carefully.

NOTE: No guarantee will be given or responsibility accepted by the manufacturers if the gate is not installed as instructed. Barrier Group <u>do not</u> warrant the work of 3rd party contractors.

BEFORE YOU START

- 1. The installer must ensure the desired mounting point for the gate is level, plumb and rigid.
- 2. Use fixings appropriate to the material into which they are being fixed (not included).
- 3. Check all parts are included. Contact Barrier Group immediately if you are missing a piece.